

Gateway ID49C07U Battery Replacement

This guide will demonstrate how to replace the battery of this device.

Written By: Patrick McGrail



Step 1 — Battery



 Turn the laptop over so the bottom of the device is facing upwards with the hinge facing away from you.

Step 2





- Locate the switch on the top left of the laptop labeled with a padlock symbol.
- Flip the switch in the direction of the unlocked padlock symbol.

Step 3



 Locate the switch that releases the battery and slide it to the right.

Step 4



 While holding the release switch to the right, pull the battery away from you.

To reassemble your device, follow these instructions in reverse order.