



Toshiba Satellite C655D-S5200 Battery Replacement

This guide teaches you how to replace the battery in a Toshiba C655 series laptop.

Written By: Joseph Sctbunio



INTRODUCTION

This guide teaches you how to replace the battery in a Toshiba C655 series laptop.

Step 1 — Remove battery



- With the battery side facing you, first move the right locking latch to the right.
- Afterwards, move the left spring latch to the left, but keep your finger there, and pull the battery out with your other hand.

To reassemble your device, follow these instructions in reverse order.