Dell Inspiron 15 7579 RAM (Memory) Replacement

Remove and replace or upgrade your RAM in your Dell Inspiron laptop.

Written By: Inaki Madrigal

This document was generated on 2022-01-07 01:12:13 AM (MST).

INTRODUCTION

Upgraded RAM can help your computer run smoother. Be cautious when following guide backwards.

🔧 TOOLS:

- Phillips #0 Screwdriver (1)
- Tweezers (1)
- Metal Spudger (1)

This document was generated on 2022-01-07 01:12:13 AM (MST).

Step 1 — Back Panel

- Remove the ten 7.9 mm screws with the Phillips PH0 screwdriver.

Step 2

- Insert metal spudger into a gap in between the back panel and the back of the screen.

- Pry off the back panel using the metal spudger as a lever, and remove the back panel by lifting the rest off by hand.

This document was generated on 2022-01-07 01:12:13 AM (MST).

Step 3 — RAM (Memory)

- Fold protective flaps to the side on the RAM module located in the upper right corner of the laptop.

Step 4

- Use the tweezers to push the crimping metal away from the chip. The chip will pop up into an angled position.

- Remove the chip by pulling at the same angle as the chip with the tweezers.

This document was generated on 2022-01-07 01:12:13 AM (MST).

Step 5

- Fold the plastic flap over on the other side.

- As before, pull the fasteners away from the chip with the tweezers.

- Remove the chip by carefully pulling it out with the tweezers.

Step 6

- ⭐ When reassembling, you must match the notch in the card with the notch in the connector header shown in red.

  - Doing otherwise will break the stick if forced.

This document was generated on 2022-01-07 01:12:13 AM (MST).

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2022-01-07 01:12:13 AM (MST).