


# **Dell Precision M6700 Hard Drive Replacement**

Written By: Johnathan Hammond





Phillips #0 Screwdriver (1)



# PARTS:

- Crucial MX500 1 TB SSD (1)
- Crucial MX500 250 GB SSD (1)
- Crucial MX500 500 GB SSD (1)
- Crucial MX500 2 TB SSD (1)


# Step 1 — Battery





- Slide the release latch to unlock the battery.
  - Flip and remove the battery from the computer.


#### Step 2 — Base Cover






- Remove the screws that secure the base cover to the computer. Press the rubber tabs towards the rear of the computer to disengage the base cover.
  - Flip and remove the base cover from the computer

# Step 3 — Hard Drive




 Remove the screws that secure the primary hard drive to the computer.
Slide the primary hard -drive latch to the unlock position and pull out the hard drive from the computer.

# Step 4



- Flex the hard-drive bracket outward and pull out the hard drive from the bracket.
- i NOTE: A rubber filler is installed to the hard-drive bracket for 7 mm hard drives. It is designed to prevent vibrations and for correct installation of the 7 mm hard drives. 9 mm hard drives do not require the filler when installed into the hard-drive bracket.

# Step 5



- Remove the screw that secure that secondary hard drive in place.
- Pull the tab upward and remove the secondary hard drive from the computer.

# Step 6



- Remove the screw that secure secondary hard drive to the bracket.
- Remove the secondary hard drive from the bracket.

To reassemble your device, follow these instructions in reverse order.