




# Bendix Magneto Capacitor Replacement

Steps to replace the capacitor in the Bendix magneto.

Written By: Kelsi English



## INTRODUCTION


This guide will show you the steps necessary to remove the capacitor in the Bendix Magneto. A worn out capacitor can cause an excessive RPM drop on the left or right aircraft magneto.

---

### TOOLS:


- [Flathead Screwdriver](#) (1)  
*Size #2*
  - [Milbar snap ring plier](#) (1)
-

## Step 1 — Capacitor




- Use the #2 Flathead screwdriver to remove the five screws on the body of the magneto.

## Step 2




- Locate the two screws on the back of the magneto that holds the capacitor in place.

### Step 3



- Use the #2 Flathead screwdriver to remove the two screws.

### Step 4



- Remove the Capacitor and replace it.

To reassemble your device, follow these instructions in reverse order.