




Jam Voice Motherboard Replacement

Replacement of the Jam Voice motherboard.

Written By: Hope Bukhamseen




INTRODUCTION

Replacement of the motherboard located inside the Jam Voice will be achieved by dismantling the device. The speaker and battery must be disconnected.

TOOLS:


- [Phillips #1 Screwdriver](#) (1)
 - [64 Bit Driver Kit](#) (1)
 - [Tweezers](#) (1)
 - [Halberd Spudger](#) (1)
-

Step 1 — Hard Mesh Cover



- Insert the plastic opening tool underneath the mesh top.
 - Pry the cover open.
- ☑ To reattach the cover, simply align the round posts on the bottom of the cover into the holes.

Step 2 — Motherboard




- Remove the four 7mm Phillips screws from the plastic cover.

Step 3




- Remove the four 5mm Phillips screws that hold down the speaker in place.
- Remove the two 6mm Phillips screws that hold down the plastic casing.

Step 4




- Once all six screws are removed, use a Halberd Spudger or similar tool to lift up the speaker.
- Pull the speaker up and out.

Step 5



- Remove the four 7mm Phillips screws to expose the motherboard.


Step 6



- After removing all of the screws from the plastic cover, remove it by pulling up and out.

⚠ Be careful not to pull and damage any of the wires.

Step 7



- Remove the three 5mm Phillips screws that hold the motherboard in place.
- After the screws are removed, place two fingers on the power button and Bluetooth button to push the motherboard out.

To reassemble your device, follow these instructions in reverse order.