



# Microsoft Surface Pro 7 Kickstand Replacement

Follow this guide to replace the kickstand on...

Written By: Sam Omiotek



# INTRODUCTION

Follow this guide to replace the kickstand on your Microsoft Surface Pro 7.

Some photos in this guide are from a different model and may contain slight visual discrepancies, but they won't affect the guide procedure.

## TOOLS:

T3 Torx Screwdriver (1)

## PARTS:


Surface Pro 7 Kickstand - Genuine (1)

### Step 1 — Open the kickstand



- Lift the kickstand to expose the hinge screws.

### Step 2 — Remove the kickstand screws



- Remove the four 2.7 mm T3 screws—two on each side of the kickstand.


### Step 3 — Close the kickstand



- Move the kickstand back down to a flat position.

**i** The hinges are stiff and you may need to use some force to get it down.

### Step 4 — Remove the kickstand



- Remove the kickstand from the back cover.

**i** There are two adhesive tabs in the middle of the kickstand that disengage most easily when the kickstand is pulled directly downward from the device.

**★** Be sure to insert these tabs when reinstalling the new kickstand before replacing the screws.

**To reassemble your device, follow the above steps in reverse order.**

Take your e-waste to an [R2 or e-Stewards certified recycler](#).

Repair didn't go as planned? Try some [basic troubleshooting](#), or ask our [Answers community](#) for help.