




# Prep Black Wire

A sample guide to show how to prep a simple wire.

Written By: Russell Frampton



---

# INTRODUCTION

How to prep a black wire for XYZ job.



## TOOLS:

- [Cutter](#) (1)

Flush



- [iFixit 6 Inch Metal Ruler](#) (1)
-

## Step 1 — Wire



- Locate QCPN#10669 which is a black hookup wire.


## Step 2



- Measure out a 10cm length of wire.
  - Use a pair of flash cutters to carefully cut through the wire.
- ⚠ Caution: the wire must be no longer than 10.5cm and no shorter than 9.5cm in length.





### Step 3





- Your wire should look like this now.  
#testedit

### Step 4




- Measure 20mm from either end of the wire.
- With the flash cutters remove the insulation that is covering the wire.
- ⚠ Be careful not to cut too deep because you will damage the wire strands inside.

## Step 5



- ① Measure 10mm from the other side of the wire.
- Remove the insulation from the wire with a pair of flash cutters.

## Step 6



- Your finished wire should now look like this.
- Remember to twist of the ends of the wire with your fingers so that the wire strands are not loose.

You are finished.