



Motorola V60c Keypad and Keypad Logic Board Replacement

Written By: Ryan Kuroiwa




INTRODUCTION

How to replace the keypad and keypad logic board.

TOOLS:

- [iFixit Opening Tools](#) (1)
 - [T6 Torx Screwdriver](#) (1)
-

Step 1 — Battery



- Depress the silver button.
- Pull from top of phone to lift the cover.

Step 2



- Hold battery from both sides at the bottom.
- Push upwards and gently lift to remove.

Step 3 — Keypad and Keypad Logic Board



- Remove 4 screws from corners using T-6 screwdriver.
- ⓘ NOTE: Bottom two screws are gold.
- ⓘ NOTE: Make sure screws return to correct place when reassembling.

Step 4





- Use plastic opening tool to pry up back cover from two side clips.
- ⓘ NOTE: Sticker might be attached to rest of phone.

Step 5



- Remove the back cover.


Step 6



- Use a plastic opening tool to gently remove the orange ribbon cable.
- Lift up the main logic board.
- NOTE: Rubber side buttons are not secure and might detach from the main logic board during removal.

This document was generated on 2020-11-28 01:45:36 AM (MST).


Step 7



- Remove the keypad logic board.

i NOTE: Plastic spacer is not secured to keypad logic board and might detach during removal.

Step 8



- Remove the keypad.

To reassemble your device, follow these instructions in reverse order.