

# HP ProOne 600 G1 Solid State Drive Replacement

This computer has a 256GB solid state drive. Whether it needs replacement due to failure or it is desired to upgrade to a larger size drive, this guide is applicable.

Written By: Janelle Layman



This document was generated on 2020-11-21 12:51:41 PM (MST).

#### **INTRODUCTION**

The maximum dimensions of a new solid state drive are 100.5 x 69.85 x 7.0mm. Before performing any work, always remember to completely turn off and disconnect your computer from any power source.



# **TOOLS:**

• T15 Torx Screwdriver (1)

### Step 1 — Solid State Drive






 Push the unlock tabs on the back of the monitor in and towards each other while sliding the back cover up.

# Step 2




 Pull up on the hard drive bay handle and push it to the left while holding back the metal tab on the bottom.

### Step 3



 Pull side latch out and slide the hard drive tray out of the bay.

### Step 4



• Remove the four 5/16" side screws, with the T15 Torx Screwdriver, and gently take out the drive.

To reassemble your device, follow these instructions in reverse order.