


Harman Kardon Onyx Studio 2 Bluetooth Antenna Replacement

If your Onyx Studio 2 no longer has Bluetooth connectivity, follow this guide to replace the entire Bluetooth antenna.

Written By: Alexandra Achtenberg



This document was generated on 2020-11-28 05:40:20 AM (MST).

INTRODUCTION

After removing the control board and circuit board, the Bluetooth antenna can be accessed and therefore removed. This is helpful if a lack of Bluetooth connectivity is due to the speaker.



TOOLS:

- T10 Torx Screwdriver (1)
- iFixit Opening Tools (1)

Step 1 — Front Panel







 Using a plastic opening tool, pry off the front grill by wedging it in the notch on the front of the device.

Step 2





Remove the five 14.4 mm T10 Torx screws.


Step 3



 Gently pull the front apart from the back.


Step 4





- Remove the four wires connecting the front and back panels.
- Pinch the connector tab and pull gently upwards.
- Repeat for the other three connectors.

Step 5 — Control Board



 Pull the silicone button band off of the outer edge of the speaker.


Step 6





• Disconnect the two pressure connections from the circuit board.

Step 7






- Gently remove the control board band by placing fingers in contact with it through the button openings.
- (i) Work from the outer edges in so as not to bend the band.


Step 8 — Circuit Board





- Disconnect the remaining connectors from the circuit board.
- Disconnect the Bluetooth antenna.


Step 9






- Remove the four 10 mm T10 Torx screws.
- Pull the circuit board out of the device as it is now free.

Step 10 — Bluetooth Antenna





- Using the wide blue plastic opening tool, gently peel back edges of the Bluetooth board.
- Peel off completely and remove from the device.

To reassemble your device, follow these instructions in reverse order.